

スロットルスティックを使ってタイマー操作を行う設定手順

1 スティックポジションスイッチの設定

■SYSTEM LIST 1/3
MODEL SEL. TRIM SYS.
COPY/ERASE **STK POS SW**
TYPE SEL. TRIM IN SW
MODEL NAME STK ALERT
FM NAME WARNING

■STICK POS SW ▶ INH 1/2
SPS0: **INH**

■STICK POS SW ▶ INH 1/2
SPS0 STICK
INH ELEV
THRO RUDD
AILE

■STICK POS SW ▶ OFF 1/2
SPS0: **THRO** ON
SYM: OFF
AREA: HIGH
POS: 0 OFF

■STICK POS SW ▶ OFF 1/2
SPS0: THRO ON
SYM: OFF
AREA: HIGH
POS: 0 OFF

■STICK POS SW ▶ OFF 1/2
POS
L 90 ON
OFF

■STICK POS SW ▶ OFF 1/2
SPS0: THRO ON
SYM: OFF
AREA: HIGH
POS: **L 90** OFF

2 タイマースタート / ストップスイッチの設定

スタートスイッチの選択

■FUNCTION LIST 3/3
THRO TRIM ▶MY LIST
TIMER ▶SYS.LIST
MIX MONIT.
MONITOR

■TIMER
TIMER1 TIMER2
DOWN 10:00 INH
START SW
STOP SW
INTEG. TIMER: 4:25

SW SEL AND: 0 1/3
FM-0 ☐ **SPS0** ☒
FM-1 ☐ SPS1 ☐
FM-2 ☐

ストップスイッチの選択

■TIMER
TIMER1 TIMER2
DOWN 10:00 INH
START SW
STOP SW
INTEG. TIMER: 4:27

SW SEL AND: 0 1/3
FM-0 ☐ **SPS0** ☒
FM-1 ☐ SPS1 ☐
FM-2 ☐